

CLR UNV GC1F FENDER MOUNT (29394 KIT) COOLER KIT Installation Instructions

Locate the cooler bracket and cooler on the rear fender so that the bag rack and golf bag will not interfere with the removal of the cooler.

Hold the bracket in position and mark the four mounting bolt holes. Drill the four holes with a 1/4" drill bit. Install the bolts and nuts by reaching under the rear body and fender area. The six rubber spacers (included) are used on some cars to level the cooler.

On some cars, such as Yamaha G16 models, you can cut a hole in the underside fender well to install the bolts and nuts. A Dremel or similar cutting tool or a hole saw works well for that.

For The Drive models, remove the four wheel well rivets and remove plastic wheel well cover. This will expose the bracket mounting holes just drilled making the nut/bolt installation much simpler. You can reuse the rivets for wheel well cover.

